




the future is safer with altro

altro  
transflor


## Flooring Cleaning Guidelines




1. Sweep up dust and dirt, remove large debris.



2. Fill one half of double bucket with warm water.




3. Dilute Altro 44™ or recommended Autoglym detergent to correct dilution.




4. Pour diluted cleaner into other half of double bucket.




5. Apply cleaner to floor using a mop.




6. Leave cleaner on the floor for a few minutes to allow solution to break up dirt.



7. Scrub the floor with a deck scrubber or Altro UniPad cleaning pad attached to multi-mop handle.



8. Rinse the floor using a mop and the clean water from the double bucket.



9. Allow to dry.

Altro safety flooring can be steam cleaned as follows:

- 1 Nozzle temperature when steam cleaning to be limited to a maximum of 120°C and pressure to be maximum of 4 bar = 60psi.
- 2 Brush adaptor to be used.
- 3 Never use a "small" nozzle adaptor.
- 4 Never use any detergents in combination.



[www.autoglym.com/psv](http://www.autoglym.com/psv)

For advice on your flooring maintenance regime please contact your local representative.

Altro Ltd, Works Road, Letchworth Garden City, Herts, England SG6 1NW  
Tel: +44 (0)1462 480480 Fax: +44 (0)1462 480010 e-mail: [transflor@altro.com](mailto:transflor@altro.com)

[www.altrotransflor.com](http://www.altrotransflor.com)